

TERMINAL CONFIGURATIONS

Terminal shapes vary from one battery to another. By identifying the correct replacement battery from the listing in this book, you are assured of the proper terminal configuration.

19

For custom applications,
refer to the following chart to identify
terminal shape and corresponding batteries.

| TERMINAL TYPE | FRONT | SIDE | TOP | BATTERY TYPE |
|---------------|-------|------|-----|--|
| 1 | | | | PTX16-BS-1, CB7C-A, CB14L-A1 |
| 2 | | | | CB9L-A2, CB16AL-A2 |
| 3 | | | | CB7L-B, C60-N24L-A, C60-N24AL-B, 12N24-3 |
| 4 | | | | PTX14AHBS-FS, PTX14AHLBS-FS, PTX14BS-FS, PTX15LBS-FS, PTZ16H, PTX20BS-FS, PTX20LBS-FS, PIX50LBS-FS, PTX14AH-BS, PTX14AHL-BS, PTX14-BS, PTX14L-BS, PTX15L-BS, PTX16-BS, PTX20CH-BS, PTX20-BS, PTX20L-BS, PIX50L-BS, PIX50L-B, CB12C-A, CB16B-A, C50-N18L-A3, CB30L-B, CB30CL-B, PAL4HY, PAL5LHY, PAL7AHY, PAL7ZSHY, PAL9HY, PAL12HY, PAL14HY, PAL14LHY, PAL14-AHY, PAL14L-AHY, PAL14ZSHY, PAL16HY, PAL20LHY, PAL50N18L-AHY |
| 5 | | | | PTX4LBS-FS, PTX5LBS-FS, PTZ5S, PTX7ABS-FS, PTX7LBS-FS, PTZ7S, PTZ8V, PTX9BS-FS, PTX12BS-FS, PTX19CLBS-FS, PIX30LBS-FS, PIX30CLBS-FS, PTX4L-BS, PTX5L-BS, PT6.5L-BS, PTX7A-BS, PTX7L-BS, PTX9-BS, PTX12-BS, PTX19CL-BS, PIX30L-BS, PIX30CL-BS, CB4L-A, CB4L-B, CB16CL-B |
| 6 | | | | PTX12AABS-FS, PTX19BS-FS, PTX19LBS-FS, PTX19-BS, PTX19L-BS, PT9A-BS, CB16-B-LM, CB16H-L-AM, CB3L-A, CB3L-B, CB5L-B, CB7-A, CB9-A, CB9L-B, CB10L-B, CB12A-A, CB12AL-A, CB12A-B, CB14A-A, CB16-B, CB16L-B, 6N6-3B, 6N6-3B-1, 6CB8L-B, 6N11-2D, 6N11A-1B, 6N12A-2D, B38-6A, B39-6, B54-6, 12N5-3B, 12N5-4B, 12N5.5-3B, 12N5.5-4A, 12N5.5A-3B, 12N7-4A, 12N7-3B, 12N7D-3B, 12N7-4B, 12N9-3A-1, 12N9-3B, 12N9-4B-1, 12N10-3A-1, 12N10-3A-1, 12N12A-4A-1 |
| 7 | | | | C50-N18L-A-LM, CB16B-A1, HCB16A-AB, CB18-A, CB18L-A, C50-N18A-A, SC50-N18L-AT |
| 8 | | | | CB10A-A2, CB10L-A2, CB10L-B2, CB12AL-A2, CB12B-B2, CB14A-2, CB14A-A2, CB14B-2, CB14L-A2, CB14L-B2, SCB14L-A2, SCB14L-B2, 12N11-3A-1, 12N14-3A |
| 9 | | | | CHD4-12 |
| 10 | | | | 51913-FS, 51814, 51913, 53030 |
| 11 | | | | PT6B-3, PT7B-4, PT9B-4, PTZ10S, PT12B-4, PTZ12S, PT14B-4, PTZ14S, PTX12ABS-FS, PTR9-BS, PTX12A-BS |
| 12 | | | | PTR4A-BS |
| 13 | | | | PTX4B-BS |
| 14 | | | | P11U1LD-FS, U1(9), U1(9)R |
| 15 | | | | PTX20HBS-FS, PTX20HLBS-FS, PIX30HLBS-FS, PIX32HLBS-FS, PAL20LHY-H, PAL30LHY-H |
| 16 | | | | PTX14LBS-FS |
| 17 | | | | P26RH-FS |

FURTHER INFORMATION

Please refer to our website www.power-sonic.com for product catalogs, safety data sheets (SDS), ISO certification, etc.